



- 1) Use 1/4" Drill Bit**
- 2) Use anchors when mounting to dry wall**
- 3) Allow for 5" of empty space above unit so that the lid can be opened fully**